

## New and Old iPhone and iPad Gestures

Action Desired	iPhone X Gestures	All I Devices with a Home Button
<b>From the Lock Screen</b>		
Access Home Screen	Sweep up from the bottom (the line at the bottom) if you have face ID setup Sweep up from the bottom and enter Passcode.	Press the Home Button if you have fingerprint ID Press the Home Button and enter passcode, or press the Home Button if you do not have passcode
Access the Control Center	Sweep down from the top right	Sweep up from the bottom of the screen
Turn on Flashlight	Touch and hold the Flashlight	Access control center then tap flash
Turn of Flashlight	Touch and hold Flashlight when on	Access control center then tap flash
Open the Camera to take a picture	Touch and hold the Camera	
Open the Camera to take a picture	Sweep from right to left	Sweep right to left in the middle of the screen
Open Widgets screen	Sweep from left to right	Sweep from left to right
To go to Home Screen if phone identified your face	Sweep up from to bottom	NA
Goes to the "enter your unlock code" screen if phone does not identify your face	Sweep the bottom line up from the bottom	Press Home Button if you do not have a finger print reader or have not set one up
To access the Magnifier	Open Control Center and tap magnifier icon	Open Control Center and tap magnifier icon
To access the Magnifier	Triple tap the Power Button	Triple tap the Home Button
To access Wallet	Double tap the Power Button	Double tap the Home Button
To access Siri	Press and hold the Power Button	Press and hold the Home Button
To Access emergency info	Tap the Power Button 5 times	Tap the Power Button five times
<b>From the Home Screen</b>		
Access the Control Center	Sweep down from the top right	Sweep up from the bottom
Access the Notification Screen	Sweep down from the top left	Sweep down from the top
Access the Widget center (return to home by sweeping right to left	Sweep from left to right	Sweep from left to right
To access all the open applications	Sweep up from off the screen and hold then release	Double tap the Home Button

## New and Old iPhone and iPad Gestures

To stop an application from running	Sweep up from the bottom to view the apps that are running. Tap and hold one of the application to make it shake. The open application icons will start to shake, with a red circle at the top left corner of each application, to <b>stop a running application</b> tap the red circle, or sweep up on the application icon.	Double tap the Home Button to view the apps that are running. Then sweep up on the application you want to stop.
To access an application that is already running.	Sweep up from off the screen and hold then release. Then tap on the application you wish to reopen	Double tap the Home Button, then tap on the application you wish to re-open.
To delete an app icon from the Home Screen (Device).	Press and hold any icon on the home screen. Then tap the x on the upper left corner of the app you want to remove. Then tap the word Delete.	Press and hold any icon on the home screen. Then tap the x on the upper left corner of the app you want to remove. Then tap the word Delete.
To access the Magnifier	Triple tap the Power Button, or open control center then tap the magnifying glass with a + in the middle	Triple tap the Home Button, or open control center then tap the magnifying glass with a + in the middle
To access the Flashlight	Open control center then tap the Flashlight	Open control center then tap the Flashlight
<b>From Any application</b>		
Return to home screen	Sweep the line at the bottom up	Press the Home Button
Goes to another open application	Sweep the line at the bottom to the left or right	Go back to Home screen and open the application you want
To access the magnifier	Triple tap the Power Button	Triple tap the Home Button
<b>Other Actions</b>		
To access Siri	Press and hold the Power Button	Press and hold the Home Button
To take a Screen shot	Press Power and Volume Up button at the same time	Press the Power and Home Button at the same time
To access the wallet	Press and release the Power Button Twice	N/A
To access the emergency info.	Press and release the Power Button 5 times	Press and release the Power Button 5 times
To take a screen shot	Press and release the power and volume buttons at the same time.	Press and hold the Power Button and the Home Button at the same time