

ANDROID COVER

MMM YY

1. **NOTIFICATIONS:** SWIPE to delete (some will, some won't)
2. **TETHER:** Plug your phone into your Laptop to provide Laptop with Internet access. (high data c
3. **MULTI-TASKING:** Suspend one App and run another, come back to first. (most apps Suspend,
4. **From an APP,** tap HOUSE (OR double box below screen) (It suspends App 1), go to App 2,
5. **WIDGETS:** A type of service APP: Utilities that run all the time: Clock
6. **DELETE APP:** Tap **Settings**, Applications, Application Manager, tap an App. Shows memory in u
7. **TOUCHES:** Learn the Touches: 1. Tap, 2. Hold for 3 secs, 3. Slide across the screen w/o selec
8. Hold Power for less than 3 secs to turn off screen, for 3 secs to power down phone.
9. **BACKUP TO A WINDOWS HD:** plug in USB cable & view hard drives in Explorer: drag and drop
10. **CAPTURE SCREEN:** Press and Hold down Decrease Vol and hold Power until to see/hear action.
11. **Radiation:** Wi-Fi (300 ft), Internet (6 mi to tower), Blue Tooth (9-30 ft). Do NOT hold to ear/He
12. Apps live in two kinds of memory: RAM and SD chip. Add chip (\$9) if don't have.
13. Check **RAM** usage at Settings/Storage. [avail space near bottom]
14. Check **SD** card usage at Settings/Storage.
15. Look on **PLAY STORE** for app **Move2SD** (others will appear also). Lists Apps, choose App to m
16. **SD** is called **Internal Storage**. When **Move-To-SD** button is done, label changes to **Move To Inte**

Missing Clues:

17. / (looks like a pen) mean Edit Mode
18. X is a CANCEL BUTTON but usually just Suspends App, like the BACK arrow at bottom of pl
19. + means add a new entry on screen
20. Menu at top can be 3 lines or 3 horizontal dots
21. Check mark means Done/Exit screen
22. Settings is a gear/cog wheel

www.MdeWebs.com